Assembly Instructions

RUSTIC TIERED WATER FEATURE



ASSEMBLY STEPS

1. Place the pump in the Tier 2 bowl. Thread the pump power cord through the hole.
2. Thread the power cord through the pedestal base and turn the Tier 2 bowl to lock it to the pedestal.
3. Turn and lock the top to the Tier 1 bowl, and connect the pump to the hose. Lock the Tier 1 bowl to the Tier 2 bowl. Put the pump door lid on the pump door.
4. Connect the water pump to the power cord and fill with water.

CARE & SAFETY

- Use a soft cloth to clean the fountain. Never use acidic or alkaline cleaning agents; these may damage the painted finish.
- Change the water regularly. Prevent leaves and foreign objects from accumulating in the reservoir.
- If water does not flow, switch the pump off and on. If needed, disconnect power and inspect the pump and supply tube for blockages.
- Disconnect the power supply before performing any of these operations.